


T.Z. CASE

Instruction Guide for Setting Combination locks


The following instructions will assist you in setting your combination lock. Please note the following important information:

- **DO NOT** forget the combination you have set. Once the combination is set and the case is locked, there is no way to open it without your combination. Be sure to write down your combination and store it in a safe place.
- After setting your combination, do not move the numbers while depressing the button (as shown in Figure 3). To do this would reset the combination.
- For your safety and security, T.Z. Case cannot override your set combination. If your combination is lost or has been forgotten, the only way to open the lock would cause damage to the lock and/or the case, and T.Z. Case is not liable for such damage under the terms of our warranty.


1. REMOVE RED SECURITY TABS FROM THE COMBINATION WHEEL. (APPLIES TO FIRST TIME USE ONLY)




2. PUSH BUTTON TO THE **RIGHT** TO RELEASE THE LOCK. **KEEP LOCK OPEN** DURING SETTING PROCESS.




3. PUSH RELEASE BUTTON TO THE **LEFT** (OPPOSITE DIRECTION OF OPENING), AND **HOLD** THE BUTTON THRU **STEP 4**.




4. SET NUMBER WHEELS TO THE DESIRED COMBINATION.



5. ONCE THE LOCK IS SET **RELEASE** THE BUTTON.



6. TO VERIFY YOUR COMINATION, LEAVE THE CASE **OPEN** AND CHANGE THE NUMBER WHEELS TO RANDOM NUMBERS. NOW, PUSH BUTTON TO THE **RIGHT** AND **ENSURE THE WHEELS ARE LOCKED**. IF THE BUTTON MOVES, THIS MEANS THE NUMBER WAS NOT SET, AND YOU MUST REPEAT THE STEPS.



7. ENTER YOUR CODE AND PUSH BUTTON TO THE **RIGHT** TO VERIFY THE COMBINATION LOCK WORKS.